
Meridian Administration Tools

MAT Station Administration

User Guide

Document Number: P0843834
Document Release: Standard 5.7
Date: July 1997

© 1996, 1997
All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

Release Date	Document Version	Supported Release
October 1997	Standard	5.7
July 1997	Preliminary	5.7
April 1997	Standard	5.6
September 1996	Standard	5.0
July 1996	Standard	4.0
January 1996	Standard	3.5
December 1994	Standard	2.0
June 1994	Standard	1.1

Contents

Introduction	1
Overview	1
MAT Users	2
Conventions used in this manual	2
 Station Administration	 3
Overview	3
Station Data Considerations	3
Location	4
DES	4
Sync Status	5
Synchronization Considerations	5
Reports and Text Files	6
Parsing Retrieved Data	6
Multi-Tenant	6
System Hardware	7
Station Administration window	7
File Menu	8
Edit Menu	9
View Menu	9
Synchronize Menu	10
Forms Menu	10
Options Menu	10
Help Menu	11
Accessing Station Data	11

The Template View	12
The Hardware View	12
New Stations	12
Station Template	13
Add Stations	13
Adding a Single Station	14
Adding Multiple Stations	14
Adding the Stations	15
Deleting Stations	15
Adding a Station Template	16
Managing Station Data	17
Updating Stations	17
Station Data	17
Key Assignments	19
Directory Number Assignment	20
Terminal Number Assignment	22
Features Button	23
Administration	26
Designation Strips	27
Designating Directory Numbers	28
Display of Designation Strips	28
Station Data Validation	29
Validating the Data	29
CPND	31
CPND Overview	31
CPND Data Considerations	31
CPND Names vs. Station Names	32
CPND Synchronization	32
The CPND Module	33
Accessing CPND Data	33
CPND Administration View	34
CPND Name View	34
Recommended Usage	35

CPND Data Change	35
Updating the Customer Configuration Data	35
Updating the Name Display Data	36
Voice Mailbox	39
Overview	39
VMB Data Considerations	39
Administering VMB	40
Adding/Changing Stations	40
Deleting Stations	41
Changing DNS	42
VMB Data Synchronization	43
Example 1—Deleting Stations	43
Example 2—Adding a Mailbox	43
Example 3—Changing a DN	43
Global Update	45
Overview	45
Selecting Data Items	46
Define Selection Criteria	46
Example Expressions	49
Example 1	49
Example 2	50
Example 3	51
Specify the Change	51
Select the Field to Change	52
Perform the Global Change	53
Change Confirmation	54
Change Completion	54
Global Update—Wildcards, Matching, and Allowed Fields	54
Global Update—Examples	55
Communicating with Meridian 1	59
Overview	59
Communications Considerations	59

The Communications Task	61
Synchronization	61
Download	63
Retrieving All Data	63
Selecting Data to Retrieve	65
Retrieve Since Option	66
Specifying Data to Retrieve	66
Upload	72
Selecting Data to Transmit	72
Synchronization status and Retrieval	72
Communications Logs	73
Viewing large log files	74
Transmission errors during retrieval	75
Conversion utility	77
Overview	77
Starting the Conversion utility	77
File Menu	78
Rebuild File Menu	78
Help Menu	79
Rebuilding Files	79
Accessing the Files	79
Monitor Rebuilding Files	79
Importing Station Data	80
Considerations When Merging Key Values and Features	80
Select a Data File	81
Select a Field File	81
Perform the Merge	81
Example of Import Data	82
Generating Reports	83
Overview	83
Reports Considerations	83
Starting the Reports Function	84

File Menu	84
Forms Menu	85
Reports Menu	85
Running Reports	85
Select a Report	85
Select a Destination	87
Print Report	87
View Report	87
Export Report	89
The MAT File Viewer	91
Overview	91
Viewing a File	91
Viewer File Menu	91
Viewer Search Menu	93
Changing Viewed Data	93
Browsing the File	93
Save As	93
Display a File Summary	94
Print from the Viewer	95
Search the File	95
Printer Setup	96
Exit the Viewer	97
Designing Report Forms	99
Overview	99
Form Section Concepts	99
The Forms Editor	100
File Menu	100
Edit Menu	101
Section Menu	102
Field Menu	103
Options Menu	103
Fonts Menu	104

Changing Sections	104
Insert a Section	104
Define Section Parameters	104
Edit a Form	107
Insert a Field	107
Insert Data Field	108
Insert Calculation Field	108
Insert System Field	109
Edit Field Attributes	109
Edit Text Field Attributes	109
Edit Numeric Field Attributes	110
Edit Date Field Attributes	112
Edit Calculation Field Expression	113
Setting Report Parameters	113
Character Formatting	114
Font Selection	114
Report Criteria	115
Building a Report in the MAT Report Generator - Form Editor	115
Decide what information needs to be displayed on the report	116
Select the Report view that best provides the information	118
Place the individual data fields on the report	119
Decide if the report lines should be sorted	123
Specify any special printer considerations for this report	124
Apply the finishing touches	125
Save the report and test the results	129
Some Special Techniques	130
Power User Tool	133
Concepts for the Power User tool	133
Forms and templates	133
Filters	134
Using the power user Forms interface	135
Forms interface window buttons	135
Forms interface message bar	135
Keyboard shortcuts	135

Adding a single station or template	136
Updating a single station (or template)	140
Adding multiple stations	140
Validating station data	143
Field validation	143
Station validation	143
Validating the numbering plan and hardware	143
Station fields	144
On-line Help	144
Types of Station field	144
Class of service field	144
Mutli-line keys	145
Single line FTR's	145
Prompts	145
DN and TN fields	145
TN fields	146
DN fields	146
CPND Parameter Fields	149
Designing forms and templates using the forms editor	152
Creating a new form	152
Editing an existing form	153
Feature Groups and MNEMONICS	157
Features and Feature Groups	157
Key Features	166